




704 Beacon Lake Drive Raleigh, NC 27610
Tel: (919)255-3335 Fax: (919)255-3319
<http://www.deejayseventrentals.com>

Frozen Drink Instructions – Use & Cleaning

How to use:

Selection of the right (snowflake) position, with both switches, will schedule the machine for normal operation. The compressor cycle is protected by a time delay circuit, which will engage the compressor approximately 2 minutes after normal operation is initiated. A red fill light located above the switches will illuminate when the level of mix is low in the hopper. A thermostat knob on the electrical control box of your machine is set at the factory and should not be changed or adjusted except by an authorized service repairman.



CLEANING

- (1) Drain mix into a sanitized container as per local health code procedures.
- (2) Turn the machine to the off, “hand” position. remove hopper cover. Look in the hopper to locate and remove the **float and float clip** for cleaning.
- (3) Pour two gallons of cool (75°F.) water into the hopper. Clean the hopper and feed hole. Place upper switch in “faucet” position to let the machine stir for 2 minutes. Turn machine “OFF”, drain and dispose of the rinse water. Repeat until water is clear.

CAUTION: Do not pour hot water into a cold or cool machine as it can crack the cylinder and destroy the machine.