

Front

(1a) Inflatable Screen

(1b) Blower

Rear

(2a) Primary Speaker

Speaker Connections:

- Primary to Secondary Speaker (XLR to XLR cable)
- Power Plug to outlet
- In from DVD/Laptop (IPOD Cable or RCA to 1/4in or 1/8in)

(2b) Secondary Speaker

(3)

4ft A/V Table (minimum 7ft from screen)

- DVD Player/ Laptop (play video)
- Projector (project image)

Connections:

- DVD/Laptop out to Primary Speaker (IPOD Cable or RCA to 1/4in or 1/8in)
- DVD/Laptop out to Projector (HDMI or RCA to RCA or) *If using HDMI to HDMI- you may have to reselect speaker option on your computer. Instructions in Projector case.

(4)

7kvh Generator/Cords

Connection to Power:

- DVD Player/Laptop
- Projector
- Both Speakers
- Screen Blower
- Popcorn (if applicable)

INSTRUCTIONS:

1. Setup rear projection screen and attach blower.
2. Setup Speakers behind screen as close as possible to the left and right side edges of screen.
3. Setup 4ft table for DVD/Laptop and Projector: *approx. 7-14ft behind screen.*
4. Setup Generator and run power cords to all devices.
5. Follow “**Connections**” sections to connect all devices with cables; (i.e., DVD/laptop to Projector to show image, DVD/laptop to speaker to play sound, etc.)

****EQUIPMENT MUST NOT BE LEFT OUTSIDE OVERNIGHT OR FEES MAY APPLY. ****